USER MANUAL

OLIGHT

Seeker 4 Pro
Silver-Plated Bronze

A powerful flashlight with a multifunctional holster.

IN THE BOX

Table 1: SPECIFICATIONS

CREE XHP35 CCT: 5700K~7000K CRI:70
NICHIA 219B CCT: 4000~5000K CRI:70

TURBO	4300 lumens	2 hours	4.5 meters
HIGH	1200 lumens	4 hours	2.5 meters
MEDIUM	350 lumens	12 hours	1.5 meters
LOW	100 lumens	36 hours	0.5 meters
MOONLIGHT	1 lumen	720 hours	N/A

Rechargeable Li-ion battery (included: 1pc 21700)

Battery dimensions (included: 21700)

* Above data are tested per IAU/PLATO C 1.2019 standard in OlLight's Ulbrichtsphere

MCC (Optional Accessory)

Cable length	0.2m
Input	5V
Output	DC5V 4.2A+5.0W 2.0A
Time to fully charge	About 2.5 hours

Note: The MCC is not included in the package, if necessary, please purchase it separately.

Table 2: USB-C Charging Cable

Charge Type	USB-C
Cable length	0.2m
Input	5V 2A
Output	5V 2A
Time to fully charge	About 3.5 hours

Figure 2
Charging



Figure 3
Lockout

After being turned off, it will be locked out automatically. If no operation is made within 10 seconds after the indicators are off.

Figure 4
Unlock

Rotate the switch in any direction more than 90° to unlock.

Figure 5
On/Off

Press

Figure 6
Moonlight

Figure 7
Turbo

Figure 8
Strobe

Figure 9
Change Brightness Level

Figure 10-1
While on: Stepless increasing and decreasing

Figure 10-2
While on: Stepless increasing and decreasing

Figure 11
Timer

Figure 12
How to use the holster

Figure 13
How to use the fixing bracket

Figure 14
How to take the vertical holster out of the fixing bracket

Figure 15-1
Brightness level indicators



Figure 15-2
Battery Level Indicators

Figure 16
Unlock

Figure 17
Lockout



Figure 18
Change brightness level

Figure 19
Turbo

Figure 20
Strobe

Figure 21-1
While on: Stepless increasing and decreasing

Figure 21-2
While on: Stepless increasing and decreasing

Figure 22
Timer

Figure 23
How to use the holster



Figure 24
How to use the fixing bracket

CONTENTS

(EN) English 01
(CN) 简体中文 02
(FI) Finnish 04
(NO) Norwegian 05
(SV) Swedish 06
(NL) Nederlands 07
(PL) Polska 12
(CZ) Deutsch 14
(HU) Magyarország 16
(ES) Español 21
(RO) Romanesc 24
(UA) Українська 26
(JP) 日本語 29
(KR) 한국어 31
(TH) ไทย 33
(FR) Français 35
(IT) Italiano 38
(SK) Slovenskojazyk 40
(PT) Portugués 42

(EN) English

Multi-language dictionary see Table 3.

1. Product parameters, see Table 1 and Table 2.

2. Operating instructions as below:

2.1 Charging, see Figure 2.

2.1.1 Indicator for Charging, see Figure 2.

While charging, the battery level indicators on the dashboard will be sequentially illuminated. When it is fully charged, all battery level indicators will be lit.

2.2 Lockout, see Figure 3.

After turned off, it will be locked out automatically if no operation is made within 10 seconds after the indicators are off.

2.3 Unlock, see Figure 4.

Rotate the switch in any direction more than 90° to unlock.

2.4 On/off, see Figure 5.

Press the switch for short to turn on/off. If it is turned on, it will be locked out automatically if no operation is made within 10 seconds after the indicators are off.

2.5 Moonlight, see Figure 6.

Press and hold the switch for 1 second to turn on/off. When the light is turned on, it will switch to the moonlight brightness level. The high mode and above mode are not available in this mode. The low mode and above mode are available in the turbo mode. The low mode and above mode are available in the strobe mode. The low mode and above mode are available in the SOS mode. The low mode and above mode are available in the beacon mode. The low mode and above mode are available in the SOS mode. The low mode and above mode are available in the beacon mode. The low mode and above mode are available in the SOS mode. The low mode and above mode are available in the beacon mode.

2.6 Turbo, see Figure 7.

Double press the switch to enter turbo mode, double press again to return to the memorized mode.

2.7 Strobe, see Figure 8.

Triple press the switch three times to enter strobe mode, double press again to return to the memorized mode.

2.8 Change brightness level, see Figure 9.

Press and hold the switch for 1 second to turn on/off. When the light is turned on, it will switch to the moonlight brightness level. Continue to press and hold the switch for 1 second to turn on/off. When the light is turned on, it will switch to the turbo brightness level. Continue to press and hold the switch for 1 second to turn on/off. When the light is turned on, it will switch to the strobe brightness level. Continue to press and hold the switch for 1 second to turn on/off. When the light is turned on, it will switch to the moonlight brightness level.

2.9 While on: Stepless increasing and decreasing, see Figure 10-1.

While on: Press the switch continuously for short to increase the brightness. When the brightness level reaches the maximum, it will flash twice. Press the switch continuously for short to decrease the brightness. When the brightness level reaches the minimum, it will flash twice.

2.10 While on: Stepless increasing and decreasing, see Figure 10-2.

While on: Press the switch continuously for short to increase the brightness. When the brightness level reaches the maximum, it will flash twice. Press the switch continuously for short to decrease the brightness. When the brightness level reaches the minimum, it will flash twice.

2.11 Timer, see Figure 11.

Double press and hold the switch under the current brightness level to enter timer mode. Blink once: 3 min. Blink twice: 6 min. Timer mode will be turned off automatically when the time is up.

2.12 How to use the holster, see Figure 12.

2.12.1 Insert the screw anchor.

2.12.2 How to use the fixing bracket, see Figure 13.

2.12.3 How to use the fixing bracket, see Figure 14.

2.12.4 How to use the fixing bracket, see Figure 15.

2.12.5 How to use the fixing bracket, see Figure 16.