USER MANUAL

OLIGHT

Baton 4 Premium Edition
Cool Daylight
A rechargeable side-switch EDC flashlight with a wireless charger.

IN THE BOX

Table 2:
Wireless Charger

Max Size	76mm
Dimensions	87*32*8mm / 3.34*1.26*0.34in
Weight	145g / 5.0oz
Battery Capacity	1000mAh (3.6V 3.6Wh)
77W-C Input	5V 3A 9V9V. Input power will be adaptive
77W-C Output	5V 2.4A 9W9V
77W-C Max Output	5V 3A 9V9V.
Time to Charge Baton 4	1.5h

Table 1:
USB-C Charging Cable

CORE, WHITE (CC: 5.1KΩ~10KΩ CR: CR1.7k)

Charge Type	USB
Cable Length	1m
Input	5V2A
Time to Charge the Wireless Charger	2.5h (Using 5V 3A 20W power source. Wear the power source capacity is sufficient, the charging time is longer)

Figure 1
Product Overview

Figure 2
Remove the insulating film before use

Figure 3
Charge the Wireless Charger

Figure 4
Change the flashlight with the charger

Figure 5
Charge external devices with the charger

Figure 6
Turn On/Off the flashlight

Figure 7
Lock/Unlock

Figure 8
Moonlight mode

Figure 9
Turbo mode

Figure 10
Strobe mode

Figure 11
Adjusting brightness

Figure 12
Auto Shut-Off function

Figure 13-1
Brightness level indicator

Figure 13-2
Battery level indicator

Figure 15
Close the bit to turn off the light

Figure 16
Moonlight mode

Figure 17
Change the flashlight brightness with the charger

Figure 18
Low battery indication

Baton 4 operation instructions
Figure 6
Turn On/Off the flashlight

Figure 7
Lock/Unlock

Figure 8
Moonlight mode

Figure 9
Turbo mode

Figure 10
Strobe mode

Figure 11
Adjusting brightness

Figure 13-1
Brightness level indicator

Figure 12
Auto Shut-Off function

Figure 13-2
Battery level indicator

Figure 15
Close the bit to turn off the light

Figure 16
Moonlight mode

Figure 17
Change the flashlight brightness with the charger

Figure 18
Low battery indication

Wireless charger operation instructions
Figure 14
Turn the flashlight ON/OFF with the charger

CONTENTS

EN	English 01
CH	简体中文 02
FI	Finnish 04
NO	Norwegian 05
SV	Swedish 06
NL	Nederlands 07
PL	Polska 08
CZ	Česká 09
HU	Magyarország 10
RU	Русский 11
ES	Español 12
RO	Romanesc 13
UA	Українська 14
JP	日本語 15
KR	한국어 16
TH	ไทย 17
FR	Français 18
IT	Italiano 19
SK	Slovenčiarsky 20
PT	Português 21

EN | English

Bedienungsanleitung, siehe Table 1.
1. **Product specifications, see Table 1 and Table 2.**
2. **Product overview, see Figure 1.**
3. **Product instructions as below:**

1. Charge the Baton 4 Premium First use, see Figure 2.
During charging, the lighting ring will be constantly on. The lighting ring will be constantly on. The lighting ring will be constantly on. The