USER MANUAL

OLIGHT

IN THE BOX

Figure 1
Product Overview

Table 2:
Wireless Charger

Wave Body	Plastic
Dimensions	70mm(L) x 38.5(W) x 20(H)
Weight	34g / 1.2oz
Battery Capacity	1000mAh (3.6Wh)
Battery Capacity	1000mAh (3.6Wh)
USB-C Input	5V⎓ 2A (Max) Input power will be adjusted
USB-C Output	5V⎓ 0A (Max)
Charging in Flashlight Output	5V⎓ 0.9A
Time to Charge Baton 4	2.5 hours

Table 1:
SPECIFICATIONS (Baton 4)

MODE	BEAM	OUTPUT	RUN TIME	TURBO	1.5m IK
TURBO	1000 lumens	1000 lumens	1.5 hours	1.5 hours	1.5m
HIGH	500 lumens	500 lumens	3 hours	3 hours	
MEDIUM	300 lumens	300 lumens	5 hours	5 hours	
LOW	100 lumens	100 lumens	15 hours	15 hours	
MOONLIGHT	1 lumen	1 lumen	120 hours	120 hours	

USB-C Charging Cable

Charge Type	USB-C
Cable Length	1.0m
Input	5V⎓
Time to Charge the Wireless Charger	2.5hs (Charging a 70*38.5*20mm power wireless charger with a 1000mAh battery) Input power will be adjusted, the charging time will be longer.

Figure 4
Charge the flashlight with the charger

Figure 5
Charge external devices with the charger

Figure 6
Baton 4 operation instructions

Figure 7
Lock/Unlock



Figure 8
Moonlight mode

Figure 9
Turbo mode

Figure 10
Strobe mode

Figure 11
Adjusting brightness

Figure 12
Auto Shut-Off function

Figure 13-1
Brightness level indicator

Figure 13-2
Battery level indicator

Figure 15
Close the lid to turn off the light

Figure 17
Change the flashlight brightness with the charger

Wireless charger operation instructions

Figure 14
Turn the flashlight ON/OFF with the charger

Figure 16
Moonlight mode

Figure 18
Low battery indication

Figure 19
Adjusting brightness

Figure 20
Lock/Unlock

Figure 21
Moonlight

CONTENTS

EN | English 01
CN | 简体中文 02
NO | Norwegian 03
SV | Svenskt 04
NL | Nederlands 05
PL | Polska 06
DE | Deutsch 07
HU | Magyarország 08
RU | Русский 09
ES | Español 10
RO | Romanesc 11
UA | Українська 12
JP | 日本語 13
KR | 한국어 14
PT | Português 15
FR | Français 16
IT | Italiano 17
SK | Slovenskýjazyk 18
PT | Portugués 19

Figure 13-3
Battery level indicator

Figure 16
Moonlight mode

Figure 18
Low battery indication

Figure 19
Adjusting brightness

Figure 20
Lock/Unlock

Figure 21
Moonlight

Figure 22
Strobe

Figure 23
Blinking modes

Figure 24
Lock/Unlock

Figure 25
Lock/Unlock

Figure 26
Lock/Unlock

Table 3
Multi-language dictionary

EN	Moonlight	Low	Medium	High	Turbo	Strobe	Stepless dimming	Press	Double press	Press and hold	Triple press	Blink once	Blink twice
CN	月光模式	低档	中档	高档	强档	频闪	无级调光	单击	双击	长按	三连击	单闪一次	单闪两次
NO	Månelys modus	Lav	Medium	High	Turbo	Strobe	Trinnløs dimming	Trykk	Dobbeltrykk	Hold nede	Trippeltrykk	Blink én gang	Blink to ganger
SV	Månljusläge	Låg	Medium	Hög	Turbo	Strobe	Steglös dimmning	Tryck	Dubbeltryck	Håll nedtryckt	Trippeltryck	Blink en gång	Blink två gånger
NL	Maanlicht modus	Laag	Middelste	Hoog	Turbo	Strobe	Traploze dimmen	Druk	Dubbele druk	Houd ingedrukt	Drievoudige druk	Knipper een keer	Knipper twee keer
PL	Tryb nocny	Niski	Średni	Wysoki	Turbo	Stroboskop	Płynna regulacja jasności	Naciśnij	Dwa kliknięcia	Naciśnij i przytrzymaj	Potrójne kliknięcie	Mrugnięcie raz	Mrugnięcie dwa razy
DE	Mondlicht-Modus	Niedrige Stufe	Mittlere Stufe	Hohe Stufe	Turbo	Strobe	Stufenlose Helligkeitsregelung	Drücken	Doppelklick	Gedrückt halten	Dreifachklick	Einmal blinken	Zweimal blinken
HU	Holdfény mód	Alacsony	Közepes	Magas	Turbo	Villogó	Fokozatmentes fényerőszabályozás	Nyomja meg	Kétszer kattintson	Tartsa lenyomva	Háromszor kattintson	Villanás egyszer	Villanás kétszer
RU	Режим луны	Низкий	Средний	Высокий	Турбо	Стробоскоп	Плавная регулировка яркости	Нажать	Двойное нажатие	Удерживать	Тройное нажатие	Мигание один раз	Мигание два раза
ES	Modo luz de luna	Bajo	Medio	Alto	Turbo	Estrobo	Regulación de brillo sin pasos	Presione	Doble presión	Presione sostenga	Triple presión	Parpadeo de una vez	Parpadeo de dos veces
RO	Mod de lumină	Mic	Mediu	Ridicat	Turbo	Stroboscop	Reglare fără pasuri a luminozității	Apăsare	Dublă apăsare	Ținere apăsată	Triplă apăsare	Clipește o dată	Clipește de două ori
UA	Режим місячного світла	Низький	Середній	Високий	Турбо	Стробоскоп	Безступінчасте регулювання яскравості	Натиснути	Подвійне натискання	Утримувати	Потрійне натискання	Блимає один раз	Блимає два рази
JP	ムーンライトモード	低	中	高	ターボ	ストロボ	無段階調光	押す	ダブルクリック	長押し	トリプルクリック	一回点滅	二回点滅
KR	달빛 모드	낮음	중간	높음	터보	스트로보	무단계 밝기 조절	누르다	더블 클릭	길게 누르다	트리플 클릭	한 번 깜빡임	두 번 깜빡임
PT	Modo luz da lua	Baixo	Médio	Alto	Turbo	Estrobo	Regulação de brilho sem passos	Pressione	Duplo toque	Pressione e mantenha	Toque triplo	Piscar uma vez	Piscar duas vezes
FR	Mode lumière lunaire	Bas	Moyen	Haut	Turbo	Stroboscope	Réglage de luminosité sans paliers	Appuyez	Double pression	Maintenir	Triple pression	Clignote une fois	Clignote deux fois
IT	Modalità luce lunare	Basso	Medio	Alto	Turbo	Stroboscopico	Regolazione della luminosità senza gradini	Premere	Doppio tocco	Tenere premuto	Triplo tocco	Lampeggia una volta	Lampeggia due volte
SK	Režim mesačného svetla	Nízky	Stredný	Vysoký	Turbo	Stroboskop	Bezstupňové nastavenie jasu	Stlačte	Dvojité stlačenie	Podržte	Trojité stlačenie	Bliká raz	Bliká dvakrát
PT	Modo luz da lua	Baixo	Médio	Alto	Turbo	Estrobo	Regulação de brilho sem passos	Pressione	Duplo toque	Pressione e mantenha	Toque triplo	Piscar uma vez	Piscar duas vezes

WARRANTY

We are so proud to offer a lifetime warranty in Australia, China, France, Germany, and the USA. We are also working hard to offer the same warranty in other countries. Please check the warranty policy in your country/region. Warranty is only valid if purchased from an authorized dealer. Please keep your receipt in material and workmanship under normal use, unless otherwise specified. For more information on the OLIGHT complete warranty information, please visit OLight.com or contact your local dealer.

Australia Customer Support
Austria Customer Support
Belgium Customer Support
Canada Customer Support
Czech Customer Support
Denmark Customer Support
Finland Customer Support
France Customer Support
Germany Customer Support
Italy Customer Support
Netherlands Customer Support
Norway Customer Support
Poland Customer Support
Portugal Customer Support
Romania Customer Support
Russia Customer Support
Slovakia Customer Support
Spain Customer Support
Sweden Customer Support
Thailand Customer Support
UK Customer Support
Ukraine Customer Support
Hungary Customer Support
USA Customer Support
Global Customer Support
Contact us at:
cs@olight.com

OLIGHT
Dongguan Olight E-Commerce Technology Co., Ltd.
Room 1101, Building 1, Yuanfeng Technology Park, No. 3 Dongguan Road, Changan Town, Dongguan City, Guangdong, China.